Elevator Fire & Emergency Signage

SAFETY SIGNAGE

- Plastic Non Glare finish.
- 3M full back adhesive, foam adhesive available.
- Process screen inks resist sun and light fading.
- Signs also available in full range of materials (Stainless Steel, Brass, Muntz, etc. call for pricing).
- We have the plastic metal look signs at a fantastic price.

LEXAN® FLEXIBLE DECALS

- 7 mil Lexan
 (polycarbonate) Non
 Glare, scratch resistant,
 flexible signs.
- 3M full back adhesive.
- Process screen inks resist sun and light fading.

Lexan is a registered trademark of the General Electric Corporation.

NO MINIMUM ORDER 630. 554. 8448 888. 554. 8448



SFOM-66-10 ► 6 x 6



SFOM-66-11 ► 6 x 6



SFOM-66-14 ► 6 x 6



SFOM-66-15 ► 6 x 6



SFOM-66-16 > 6 x 6



SFOM-66-16RESET ► 6 x 6



SFOM-66-17NY ► 6 x 6



SFOM-66-17 ► 6 x 6



SFOM-66-18 ► 6 x 6



SFOM-66-19 ► 6 x 6




SFOM-66-34 ► 6 x 6



SFOM-96-05 ► 9 x 6







SFOC-66-23 ► 6 x 6

PRESS "DOOR OPEN" BUTTON

STATION



SFOC-66-34 ► 6 x 6



SFOC-66-40 ► 6 x 6



SFOC-66-20 ► 6 x 6



SFOC-66-24 ► 6 x 6



SFOC-66-35 ► 6 x 6



SFOC-66-41 ► 6 x 6



SFOC-66-22 ► 6 x 6



SFOC-66-26 ► 6 x 6



SFOC-66-36 ► 6 x 6



SFOC-66-43 ► 6 x 6



SFOC-66-46 ► 6 x 6



SFOC-66-48 ► 6 x 6

Elevator Fire &

Elevator Fire & **Emergency**







SFOC-69-01 6 x 9

SFOC-66-50 6 x 6

SFOC-66-51 6 x 6

FIRE OR EMERGENCY ELEVATOR OPERATION KEY OFF NORMAL ELEVATOR OPERATION KEY ON: • PLACES ELEVATOR IN EMERGENCY SERVICE PUSH BUTTON FOR FLOOR DESIRED DOORS CLOSE ALITOMATICALLY • TO OPEN DOORS APPLY CONTINUOUS PRESSURE TO "DOOR OPEN" BUTTON **ELEVATOR** KEY RY-PASS: CAR • APPLY CONTINUOUS PRESSURE TO KEY IF CAR FAILS TO START AFTER PRESSING BUTTON FOR RETURN TO MAIN FLO

SFOC-96-04 9 x 6



SFOC-96-08 9 x 6



SFOMC-69-03 ► 6 x 9



SFOMC-69-14 ► 6 x 9





When flashing, exit elevator Insert fire key and turn to 'ON'
Press desired floor button

Press "CALL CANCEL" button

To close power-operated door

To hold car at floor

Press and hold "DOOR OPEN" buttor With doors open, turn key to "HOLD"

Press and hold "DOOR CLOSE" button

To automatically send car to recall floor With doors open, turn key to "OFF

> **PHASE 2-FH1998** 6 x 6

FIRE OPERATION

When 🔑 flashes, exit elevator

To operate car

Insert fire key and turn to "ON" Press desired button Press "CALL CANCEL" button.

To cancel floor selection

To open power

With doors open, turn key to "OFF".

To automatically send car to recall floor

PHASE 2-FH2000 6 x 6

FIRE OPERATION

When 🔑 flashes, exit elevator

To cancel floor selection

Insert fire key and turn to "ON" Press desired button.

To close power operated door

To operate car

To open powe operated door

Press and hold "DOOR OPEN" button

To hold car

With doors open, turn key to "HOLD".

To automatically send car to recall floor Turn key to "OFF".

> **PHASE 2 FH2002 PHASE 2-FH2004** 6 x 6

888. 554. 8448

NO MINIMUM ORDER

630. 554. 8448